



D - Montageanleitung GB - Assembly Instructions NL - Handleiding voor de montage
 PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
 RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
 SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



1/5

MALA

L



x 2

P



x 2

WP M8x35



x 16

UP 4,5x16



x 12

M8



x 4

M8



x 4

A7





x 2

A8



x 2



L2

L5


L6

L3

L4

L1







F



Service-Dienstverlening-Serwis-Servis-Сервисная служба-Assistenza-Szerviz


A1	A8	L2
A2	A10	L3
A3	A11	L4
A4	A13	L5
A5	E	L6
A6	F	
A7	L1	






3


3/5



4





5



6

4/5



7

