



D - Montageanleitung GB - Assembly Instructions NL - Handleiding voor de montage
 PL - Instrukcja montażu TR - Montaj talimatı RU - Инструкция по монтажу
 RO - Instrucțiuni de montaj IT - Istruzioni di montaggio FR - Notice de montage
 SK - Návod na montáž CZ - Montážní návod HU - Szerelési útmutató



1/5

Name-Naziv-Nazwa-Ölüm-Hastane-Nom-Name-Jméno-Název-Név-Önürüm

MALA

L



A1 x 2

P



A2 x 2

WP M8x35



A3 x 16

UP 4,5x16



A4 x 12

M8



A5 x 4

M8



A6 x 4

A7 x 2




A7 x 2

A8 x 2



A8 x 2



A10 x 2



A11 x 2



A13 x 3




A13 x 3



H 130



E x 4



L2

L5

L6

L3

L4

L1

F



12











Service-Dienstverlening-Serwis-Service-Сервисная служба-Assistenza-Szerviz

Typ-Type-Tipo-Típus-Tipo


A1	A8	L2
A2	A10	L3
A3	A11	L4
A4	A13	L5
A5	E	L6
A6	F	
A7	L1	




**L2****L3****L2****L3****N-1 [E+A5+A6]****N-1 [E+A5+A6]**

3


3/5



4





5



6

4/5



7

